

bosal

**Инструкция по монтажу
тягово-сцепного устройства
шарового типа 5602 F
для автомобилей
ГАЗ-3302 «Газель»**

	1995 -...
	2000
	75
	35,2



462800,

« - »

18

т. (35363) 7-05-06

факс: (35363) 7-13-20

т. (495) 785-66-07


www.bosal-autoflex.ru

« - »:	" (8182) 22-48-15
"	" 8(8442) 98-74-98
"	" 8(343) 379-39-89, 373-42-73
"	" 8(343) 26-88-308
"	" 8(3952) 710-194
"	" 8(495) 777-54-59
"	" 8(495)745-79-11
"	" 8(495) 788-95-97
"	" 8(495) 720-51-03
"	" 8(3532) 57-99-85
"	" 8-905-899-5012
"	" 8(383) 291-59-60
"	" 8(831) 279-53-24
"	" 8(3422) 98-27-20
"	" 8(342) 220-87-87
"	" 8-927-002-90-06
"	" 8(3462) 24-00-44
"	" 8(3842) 21-14-76
"	" 8-902-940-4151
"	" 8(3452) 32-22-12, 41-52-62
"	" 8-961-213-0278
"	" 8-917-347-1700
"	" 8(351) 269-44-75, 900-72-73
"	" 8(3512) 773-76-91

41.55-2005.

12,5

12 40
Ø



	1 .
	1 .
	1 .
	1 .
	1 .

	3 .
12 40	20 .
16 50	2 .
12 / .	18 .
16 / .	2 .
12	22 .
12 (.)	12 .
12 (.)	2 .
12 40 40 3	4 .
16	4 .
F	1 .
	1 .
	1 .
130	1 .
	1 .

