



**Инструкция
по монтажу тягово-цепного
устройства шарового типа 8011 А
для автомобилей
Infinity FX37**

:	2010 -...
:	1500
:	75
:	21



462800,

« - »
.: (35363) 7-05-06
/ : (35363) 7-13-20
(495) 799-13-46

www.bosal-autoflex.ru
www.bosal.com

18 "

« - »:	" (8182) 22-48-15
"	" 8(8442) 98-74-98
"	" 8(343) 379-39-89, 373-42-73
"	" 8(343) 26-88-308
"	" 8(3952) 710-194
"	" 8(495) 777-54-59
"	" 8(495)745-79-11
"	" 8(495) 788-95-97
"	" 8(495) 720-51-03
"	" 8(3532) 57-99-85
"	" 8-905-899-5012
"	" 8(383) 291-59-60
"	" 8(831) 279-53-24
"	" 8(3422) 98-27-20
"	" 8(342) 220-87-87
"	" 8-927-002-90-06
"	" 8(3462) 24-00-44
"	" 8(3842) 21-14-76
"	" 8-902-940-4151
"	" 8(3452) 32-22-12, 41-52-62
"	" 8-961-213-0278
"	" 8-917-347-1700
"	" 8(351) 269-44-75, 900-72-73
"	" 8(3512) 773-76-91

.....
.....	VIN
.....
.....

41.55-2005.


2.

(. . 1)

(

(!


).



.1

.2

1			
2			
3			
4			
5			
6			
7			



	1 .
	1 .
	1 .
	1 .
	1 .

	1 .
	1 .
	1 .

		10 1,25 40	6 .
		12 1,25 40	3 .
		12 40	10 .
		12 1,25 75	2 .
		12 /	8 .
		12 1,25 /	2 .
		10	6 .
		12	5 .
		10	6 .
		12	25 .
	1		1 .
	VH0864		1 .
			1 .
			1 .
			1 .
			1 .
			1 .

Схема обрезки кабеля

